

## YOUR PRESTO PANEL CURVING INFORMATION

Due to varying tensiles in the gauges,  
Presto Panel may be curved as follows:

0.6mm → 12mtr radius <

0.8mm → 8mtr radius <

1.0mm → 2.5mtr radius <

**Please specify when ordering your curved material:**

- ✓ Quantity of lengths, length and radius / triangular measurements of posts.
- ✓ Rib-in (rib on the inside, posts on the outside of the curve) / Rib-out (rib on the outside, posts on the inside of the curve).
- ✓ For lengths requiring a combination of straight sections & various radii, diagrams may be required.

**Rib out**

**Rib In**

### FREE CUSTOM CUTTING

You can have your Presto Panels pre-cut to your exact specifications for FREE. This means you will save on materials because you are only buying exactly what you need in the exact size that you need. You will reduce labour costs as each panel is pre-cut to suit your post spacings and you can span as many posts as you want. You will eliminate wastage and cutting equipment on site, literally grab a panel and "HEY PRESTO" attach it to your posts.

## PRESTO PANEL FOR YOUR APPLICATION YOUR GUIDE TO GAUGE USAGE

<b>Sheep Yards</b> .....	<b>0.6</b>	<b>0.8</b>	✓
<b>Shearing Sheds</b> .....	<b>0.6</b>	<b>0.8</b>	✓
<b>Undercover Pens</b> .....	<b>0.6</b>	<b>0.8</b>	✓
<b>Abattoirs</b> .....	<b>0.8</b>	<b>1.0</b>	✓
<b>Livestock Exchanges</b> .....	<b>0.8</b>	<b>1.0</b>	✓
<b>Saleyards</b> .....	<b>0.8</b>	<b>1.0</b>	✓



## YOUR PRESTO PANELS CAN BE INTERLOCKED

